



## PHD Dolphin+ Quick Reference User's Guide

---

### IMPORTANT KEYS

#### **ON.SCAN**

This key serves three purposes:

1. Turns the PHD Dolphin+ on.
2. Acts as the trigger for the laser.
3. Returns the user to the Main Menu when not in a scanning mode.

#### **BKSP**

This key serves two purposes:

1. Acts as the "**NO**" key.
2. Acts as an "**Esc**" key. Hitting this key will return you to the previous menu.

#### **ENTER**

This key acts as the "**YES**" key.

#### **F1, F2, F3 and F4**

These function keys are used to select the various menu options presented on the PHD+ Dolphin display.

#### **SHIFT**

This key controls which characters are entered when using the numbered, yellow keys on the keypad.

If the keys are in **numeric mode** (numbers will be entered when keys are used), the following symbol will be displayed in the lower left area of the PHD Dolphin+ display:

If the keys are in **alpha mode** (letters will be entered when keys are used), the following symbol will be displayed in the lower left area of the PHD Dolphin+ display:

**Note:** There is no "OFF" button. The PHD Dolphin+ will automatically turn itself off after about one minute when not in use.